

Ignore the writing!

6 mm holes are drilled for locating Tubes through both the mould base & the flange surfaces which can be removed

OCTOBER Friday Evening Workshop  
2018-10-26  
MAKING FOOTY FIN plug and moulds

Templates to check sanding plane angle of  $3^{\circ} 6'$

the sanding plane

The 2 plywood layers are bonded Together and stuck to the mould base Temporarily.

A sanding plane is bonded along the aft edge making an angle of  $3^{\circ} 6'$

The plug is sanded until the glue lines show in the right Place. This is checked by the plan to the right scale drawn On tracing paper to compare them.

Completed moulds and moulded plug with the 2<sup>nd</sup> part of the mould not polished

Completed plug and moulding flanges just waxed before moulding

This photograph was taken from the front of the plug